



**DuraLabel**

Thank you for choosing DuraLabel® Toro® Max Industrial Sign & Label System. With this standalone system, producing custom labels and signs is fast and easy. This manual shows you how to set up your new Toro Max, load supplies, and start printing.

### HASSLE-FREE REMOTE SETUP

Connect with a live technical support representative to get help setting up your new printer. Reach out to set up an appointment.

[DuraLabel.com/support/remote-printer-setup](https://DuraLabel.com/support/remote-printer-setup)

### REGISTER YOUR PRINTER

Get access to free support, software updates, and special offers.

[DuraLabel.com/register](https://DuraLabel.com/register)

### UNBOXING

Verify all items are present.



TORO MAX PRINTER




USB DRIVE




MOUSE



LABEL SCRAPER



CLEANING SWABS



POWER CORD



FIXED TABS




SUPPLY SPINDLE



STYLUS

### ITEMS SOLD SEPARATELY



LABEL STOCK






INK RIBBON



BATTERY

## SETUP

Get your printer ready to go.






**DuraLabel**  
**TORO**  
MAX  
INDUSTRIAL SIGN & LABEL SYSTEM




877-534-5157 | DuraLabel.com

## SUPPLY LOADING

### RIBBON CARTRIDGE






### LABEL STOCK



## Create and Print Labels

Time to make your first label

### PRINT FROM PREMADE SIGNS



### CREATE LABEL & PRINT

